





**Remote Web View Log-in Procedure Geo 8.02**

1. Open Internet Explorer
2. Enter URL or IP address of unit (ie: <http://127.0.0.1>)
3. Select Mpeg4 Encoder Viewer
4. Click 
5. Select Internet Connection Type: DSL and then Select MultiView
6. Click 
7. Login window pop's up.
8. Enter UserName/Password: (Default: usag/1122)
9. Click OK
10. Server Connects and viewing begins.